



Clocks, Thermometers and Humidity Meters

Carefully unpack the unit from its box and packaging.

It may be attached to the inner box by means of two or more small screws located on the back of the box.

Unscrew all of the screws on the underside of the box while supporting the unit to keep it from falling.

Battery Installation - Clock

Open the battery compartment on the rear of the unit and insert a 1.5V (AA or equivalent) battery into the battery compartment taking care to observe the correct polarity. (+/-)

Adjust the time by turning the wheel on the movement in the required direction.

Replace the rear cover by pushing it back over the movement.

Thermometer.

The thermometer is designed as a guide to determining the air temperature to within +/- 3°F. Temperature readings should only be taken when the thermometer is in the shade or has been in shaded conditions for several hours.

Occasionally after transit, the thermometer may need to be re-calibrated. This is simply completed by gripping the thermometer mechanism firmly from the rear while supporting the entire unit and carefully turning the thermometer mechanism in a counter clockwise direction to read a higher temperature or a clockwise direction to read a lower temperature.

Adjust so the thermometer's needle indicates the current accurate temperature attained from a known source, i.e. another thermometer.

Mounting and Location Instructions.

Attach the unit so that it is out of direct heat and sunlight.

Attach to a wall using suitable hardware ensuring that is firmly held in place.

Please note: Because this unit may be subjected to the elements, it is normal under certain conditions for some condensation to form on the inside face of the clock/thermometer.

This is not a defect, as airflow is required through the body of the housing in order for the thermometer to function correctly.

This condensation will clear, (but may return) dependant upon conditions and the mounting location.

Maintenance.

To ensure accurate function and long life, the front and back of the unit should be cleaned occasionally with a damp cloth to remove any accumulation of dirt.

The inside of the clock compartment should also be cleaned, either when replacing the battery or during periodic maintenance.