


# INSTRUCTIONS

## # 931 Deluxe Garden Obelisk



- Please note that frame section B is larger than frame section C. Frame section B should be assembled **on the outside** of frame section C.
- This obelisk should be securely anchored in your garden soil.
- If you have any questions, problems, assembly difficulties, or just need to contact us, please call our

customer service department at 800/327-4635. Thank you.