



Clock and Thermometer

Carefully unpack the unit from its box and packaging.

Battery Installation - Clock

While supporting the main housing, carefully grip the entire clock face and gently ease it away from the housing by pulling towards yourself.

The entire clock face and mechanism will separate from the housing.

On the rear of the clock mechanism is a battery cover. Open the cover by pulling it away from the mechanism and insert a 1.5V (AA or equivalent) battery into the compartment taking care to observe the correct polarity. (+/-)

Adjust the time by turning the wheel on the movement in the required direction.

Replace the battery cover.

Replace the clock mechanism into the main housing by gently pushing it back into position, ensuring that the number 12 is at the top.

Thermometer.

The thermometer is designed as a guide to determining the air temperature to within +/- 3°F. Occasionally after transit, the thermometer may need to be re-calibrated. This is simply completed by gripping the thermometer face and easing it away from the housing. Once the thermometer mechanism is removed from the housing, you have access to its back. Adjust so the thermometer's needle indicates the current accurate temperature attained from a known source, i.e. another thermometer.

Temperature readings should only be taken when the thermometer is in the shade or has been in shaded conditions for several hours.

Mounting and Location Instructions.

Attach the unit so that it is out of direct heat and sunlight.

Attach to a wall using suitable hardware ensuring that it is firmly held in place.

Please note: Because this unit may be subjected to the elements, it is normal under certain conditions for some condensation to form on the inside face of the clock/thermometer.

This is not a defect, as airflow is required through the body of the housing in order for the thermometer to function correctly.

This condensation will clear, (but may return) dependant upon conditions and the mounting location.